



Radio | CD | MP3 | WMA


San Diego MP27

7 647 693 510



Operating and installation instructions
Mode d'emploi et de montage
Instrucciones de manejo e instalación
Instruções de serviço e de montagem
操作及安装手册
사용 및 장착 설명서

 **BLAUPUNKT**



- ①  button
to remove the control panel (release panel)
- ② Button to switch the device on/off and operate the volume mute feature.
- ③ Volume control
- ④ CD tray
- ⑤ LCD display
- ⑥ Arrow buttons
- ⑦  button
to eject the CD from the device.
- ⑧ **ESC** button
Confirm menu item and return to the display of the MENU or AUDIO main level.
- ⑨ **DIS** button
Short press: Briefly displays alternative display contents (e.g. time).
Long press: Changes display contents.
- ⑩ **MENU** button (OK)
Short press: Calls up the menu for settings.
Confirming the menu selection (OK).
Long press: Starts the Scan function.
- ⑪ **AUDIO** button
Sets bass, treble, balance and fader.
Selects an equalizer presetting.
- ⑫ Keys **1 - 5**
- ⑬ **X-BASS** button
Switching X-BASS on/off and adjusting it.
- ⑭ **SRC/** button
Short press: Switching sources between CD/MP3, CD changer (if connected) and AUX.
Long press: Briefly displaying time.
- ⑮ **BND/TS** button
Short press: Selects the FM memory banks and the AM waveband.
Long press: Starts the Travelstore function.

Contents

| | | | |
|--|-----------|--|------------|
| About these instructions | 5 | Selecting a directory | 19 |
| For your safety | 6 | Selecting Tracks/Files..... | 19 |
| Scope of delivery | 7 | Fast search | 19 |
| Remote control | 7 | Random track play (MIX) | 19 |
| Detachable control panel | 8 | Scanning tracks (SCAN)..... | 19 |
| Switching on/off | 9 | Repeating individual tracks or whole directories (REPEAT) | 20 |
| Adjusting the volume | 10 | Interrupting playback (PAUSE)..... | 20 |
| Radio mode | 11 | CD-changer mode | 20 |
| Adjusting the tuner..... | 11 | Switching to CD-changer mode | 20 |
| Switching to radio mode | 11 | Selecting CDs..... | 20 |
| Selecting the waveband/ memory bank..... | 12 | Selecting tracks..... | 20 |
| Tuning into a station | 12 | Fast searching (audible)..... | 21 |
| Setting the sensitivity of station seek tuning..... | 12 | Configuring the display | 21 |
| Storing stations | 12 | Repeating individual tracks or whole CDs (REPEAT) | 21 |
| Storing stations automatically (Travelstore) | 12 | Random track play (MIX) | 21 |
| Listening to stored stations | 13 | Scanning all tracks on all CDs (SCAN) .. | 21 |
| Scanning receivable stations (SCAN) .. | 13 | Interrupting playback (PAUSE)..... | 22 |
| Setting the scanning time..... | 13 | CLOCK time | 22 |
| CD mode | 14 | Displaying the time | 22 |
| Switching to CD mode | 14 | Setting the time | 22 |
| Selecting tracks..... | 14 | Selecting 12/24-hour clock mode | 22 |
| Fast track selection | 15 | Displaying the time continuously when the device is off and the ignition is on | 23 |
| Fast searching (audible)..... | 15 | Sound | 23 |
| Random track play (MIX) | 15 | Adjusting the bass | 23 |
| Scanning tracks (SCAN)..... | 15 | Adjusting the treble..... | 23 |
| Repeating tracks (REPEAT) | 15 | Setting the left/right volume distribution (balance)..... | 24 |
| Interrupting playback (PAUSE)..... | 15 | Adjusting the front/rear volume distribution (fader) | 24 |
| Configuring the display | 16 | Equalizer presettings (Presets) | 24 |
| Displaying CD text..... | 16 | X-BASS | 25 |
| Ejecting a CD..... | 16 | External audio sources | 25 |
| MP3/WMA mode | 17 | Specifications | 26 |
| Preparing an MP3/WMA CD..... | 17 | Installation instructions | 152 |
| Switching to MP3 mode | 18 | | |
| Configuring the display | 18 | | |

About these instructions

These instructions contain important information to easily and safely install and operate the device.

- Read these instructions carefully and completely before using the device.
- Keep the instructions at a location so that they are always accessible to all users.
- Always pass on the device to third parties together with these instructions.

In addition, observe the instructions of the devices used in conjunction with this device.

Symbols used

These instructions employ the following symbols:



CAUTION!

Warns about laser beam



CAUTION!

Warns about damaging the CD drive



The CE mark confirms the compliance with EU directives.

- ➔ Identifies a sequencing step
- Identifies a listing

Use as directed

This device is intended for installation and operation in a vehicle with 12 V vehicle system voltage and must be installed in a DIN slot. Observe the performance limits in the technical data. Repairs and installation, if necessary, should be performed by a specialist.

Declaration of conformity

The Blaupunkt GmbH declares that this car sound system complies with the basic requirements and the other relevant regulations of the directive 1999/5/EG.

Service

In some countries, Blaupunkt offers a repair and pickup service.

Under www.blaupunkt.com, you can obtain information whether this service is available in your country.

If you want to use this service, you may request a pickup service for your device using the Internet.

Warranty

We provide a manufacturer's warranty for products bought within the European Union. For devices purchased outside the European Union, the warranty terms issued by our respective responsible domestic agency are valid.

The warranty terms can be called up under www.blaupunkt.com or requested directly from:

Blaupunkt GmbH
Hotline
Robert-Bosch-Str. 200
D-31139 Hildesheim

For your safety

The device was manufactured according to the state of the art and established safety guidelines. Even so, dangers may occur if you do not observe the safety notes in these instructions:

If you are installing device yourself

You may only install the device yourself if you are experienced in installing car sound systems and are very familiar with the electrical system of the vehicle. For this purpose, observe the installation instructions at the end of these instructions.

Observe the following!



Danger!

The device contains a Class 1 laser that can cause injuries to your eyes.

Do not open the device and do not perform any modifications.

In operation

- Operate the device only if traffic situation permits it! Stop at a suitable location to perform more extensive operations.
- Remove or attach the control panel only while the vehicle is standing an.
- Always listen at a moderate volume so that you can hear acoustic warning signals (e.g. police sirens) and protect your hearing. Do not increase the volume when selecting a different audio source or while the CD changer changes the CD. The device is briefly muted.

After operation

- The device is worthless to a thief without the control panel. Always remove the control panel whenever you leave the vehicle.
- Transport the control panel so that it is protected against impacts and the contacts cannot become dirty.

Cleaning notes

Solvents, cleaning and scouring agents as well as dashboard spray and plastics care product may contain ingredients that will damage the surface of the device.

- Use only a dry or slightly moistened cloth for cleaning the device.
- If necessary, clean the contacts of the control panel regularly using a soft cloth moistened with cleaning alcohol.

Disposal of old unit (EU countries only)



Do not dispose of your old device in the household trash!

■ Use the return and collection systems available to dispose of the old device.

Scope of delivery

The scope of delivery includes:

- 1 Car sound system
- 1 Support frame
- 2 Disassembly bar
- 1 Operating instructions
- 1 Handheld remote control RC 12H

Optional equipment (not part of the scope of delivery)

Use only accessories approved by Blaupunkt.

Steering wheel remote control

A steering wheel remote control allows for safely and conveniently operating the basic functions of your car sound system from the steering wheel.

You cannot switch the device on/off using the remote control.

You can find out from your Blaupunkt dealer or on the Internet at www.blaupunkt.com which remote controls can be used with your car sound system.

Amplifiers

You can use all Blaupunkt and Velocity amplifiers.

CD changers

You can connect the following Blaupunkt CD changers:

CDC A 03, CDC A 08 and IDC A 09.

Remote control

Your car sound system is equipped with an RC 12H handheld remote control.

Most of the functions can be operated conveniently and safely with the remote control.

Note that a line of sight must exist between the remote control and the remote control receiver, which is located in the detachable control panel.

You cannot switch the device on/off using the remote control.

Detachable control panel

Theft protection

The device is equipped with a detachable control panel (flip-release panel) as a way of protecting your equipment against theft. The device is worthless to a thief without this control panel.


Protect your device against theft by taking the control panel with you whenever you leave your vehicle. Do not leave the control panel inside your vehicle - not even in a hiding place.

The control panel has been designed to be easy to use.

Notes:

- Never drop the control panel.
- Never expose the control panel to direct sunlight or other heat sources.
- Avoid direct skin contact with the control panel's electrical contacts. If necessary, please clean the contacts with a lint-free cloth moistened with cleaning alcohol.

Detaching the control panel



- ➔ Press the **[V]** button (1).

The locking mechanism of the control panel is unlocked.

- ➔ Pull the control panel straight out of the device and to the left.


The device switches off.

All the current settings are saved.

Any CD already inserted in the device remains there.

Attaching the control panel

- ➔ Push the control panel into the guides of the device from the left to the right.
- ➔ Carefully push on the left side of the control panel until it clicks into place.



Note:

When attaching the control panel, make sure you do not push on the display.

If the device was still switched on when you detached the control panel, it will automatically switch on with the last setting activated (radio, CD, CD changer or AUX) when the panel is replaced.

Switching on/off

There are various ways of switching the device on/off:

Switching on/off using the vehicle ignition

The device will switch on/off simultaneously with the ignition if the device is correctly connected to the vehicle's ignition and you did not switch the device off by pressing button (2).

Switching on/off using button (2)

- To switch on the device, press button (2).
- To switch off the device, press and hold down button (2) for longer than two seconds.

The device switches off.

Note:

To protect the vehicle battery, the device will switch off automatically after one hour if the ignition is off.

Switching on with CD draw-in

If the device is switched off and no CD is in the drive,

- gently insert the CD with its printed side uppermost into the drive (4) until you feel some resistance.

The drive draws in the CD automatically.

You must not hinder or assist the drive as it draws in the CD.

The device switches on and CD playback starts.

Note:

If the vehicle ignition was switched off prior to inserting the CD, you must switch in on first with the button (2) to start the playback.

Switching the device on/off using the detachable control panel

- Detach the control panel.

The device switches off.

- Attach the control panel again.

The device switches on. The last setting (radio, CD, CD changer or AUX) is reactivated.

Adjusting the volume

You can adjust the volume in increments from 0 (off) to 66 (maximum).

To increase the volume,

➔ press the + button (3).

To decrease the volume,

➔ press the – button (3).

Setting the power-on volume

Note:

The device features a time-out function (time window).

For example, if you press the **MENU** button (10) and select a menu item, the device switches back after approx. 8 seconds after the last button activation. The settings performed are saved.

You can set the power-on volume.

➔ Press the **MENU** button (10).

➔ Press the **∨** or **∧** button (6) repeatedly until "ON VOLUME" appears on the display.

➔ Adjust the power-on volume using the **<>** buttons (6).

To help you adjust the setting more easily, the device will increase or decrease the volume as you make your changes.

If you enable "LAST VOL", the volume which was set the last time you switched off the device is re-enabled.

Note:

To protect your hearing, the power-on volume is limited to the value "38". If the volume before switching off was higher and the "LAST VOL" setting was selected, the device switches on again with the value "38".

When you have finished making your changes,

➔ press the **MENU** button (10) twice.

Quickly reducing the volume (Mute)

You can quickly reduce the volume to a pre-set level (Mute).

➔ **Briefly** press the button (2).

"MUTE" appears on the display.

Cancelling mute

To return to your previously set volume level,

➔ **briefly** press the button (2) again.

Adjusting the mute level

You can adjust the mute level.

➔ Press the **MENU** button (10).

➔ Press the **∨** or **∧** button (6) repeatedly until "MUTE LVL" appears on the display.

➔ Adjust the mute level using the **<>** buttons (6).

When you have finished making your changes,

➔ press the **MENU** button (10) twice.

Switching the confirmation beep on/off

The system will output a confirmation beep for some functions if you keep a button pressed down for longer than two seconds, for instance, when assigning a radio station to a station preset button. You can switch the beep on or off.

- Press the **MENU** button (10).
- Press the **∨** or **∧** button (6) repeatedly until "BEEP ON" or "BEEP OFF" appears on the display.
- Switch the beep on or off using the **<** **>** buttons (6).

When you have finished making your changes,

- press the **MENU** button (10).

Muting during telephone mode

If your device is connected to a cell phone, the car sound system is muted when you "pick up" the phone. For this purpose, the cell phone must be connected to the device as described in the installation instructions.

The display shows "PHONE".

Radio mode

Adjusting the tuner

To ensure proper functioning of the tuner, the device must be set for the region in which it is being operated. You can select among Europe (EUROPE), America (USA), South America (S-AMERICA), and Thailand (THAI). The tuner is factory-set to the region in which it was sold. If you experience problems with your radio reception, please check this setting.

The radio functions described in these operating instructions refer to the tuner setting America (USA).

- Switch off the device by pressing button (2).
- Hold the buttons **1** and **5** (12) pressed at the same time and switch on the device again with the button (2).

"TUNER" is displayed.

- Select your tuner region with the **∨** or **∧** button (6).

To save the setting,

- switch the device off and on again or wait approx. 8 seconds. The radio starts playing with the last setting selected (radio, CD, CD changer or AUX).

Switching to radio mode

If you are in CD, CD changer or AUX mode,

- press the **BND/TS** (15) button
- or
- press the **SRC/⏪** button (14) repeatedly until the memory bank, e.g. "FM1", appears on the display.

A border appears around the radio symbol.

Selecting the waveband/memory bank

This device can be used to receive stations in the FM and AM frequency bands. There are three memory banks available for the FM waveband (FM1, FM2 and FMT) and one for the AM waveband.

Five stations can be stored in each memory bank.

To switch between the memory banks FM1, FM2 and FMT or the AM waveband,

➤ briefly press the **BND/TS** (15) button.

Tuning into a station

There are various ways of tuning into a station.

Automatic station seek tuning

➤ Press the **↵** or **↶** button (6).

The radio tunes into the next receivable station.

Tuning into stations manually

You can also tune into stations manually.

➤ Press the **<** or **>** button (6).

Setting the sensitivity of station seek tuning

You can choose whether the radio should only tune into stations providing good reception or whether it can also tune into those with a weak reception.

➤ Press the **MENU** button (10).

➤ Press the **↵** or **↶** button (6) repeatedly until "SENS" appears on the display with the current setting.

"SENS HI" means that the tuner is set to the highest sensitivity setting. "SENS LO" means it is set to the lowest sensitivity setting.

➤ Set the desired sensitivity level using the **<>** buttons (6).

When you have finished making your changes,

➤ press the **MENU** button (10).

Note:

You can adjust different sensitivities for FM and AM.

Storing stations

Storing stations manually

➤ Select the desired memory bank FM1, FM2, FMT or the AM waveband.

➤ Tune into the desired station.

➤ Press and hold down one of the station buttons **1-5** (12) for longer than two seconds to assign the station to that button.

Storing stations automatically (Travelstore)

You can automatically store the five strongest stations in the region. The stations are stored in the FMT or AM memory bank.

Note:

Any stations that were previously stored in this memory bank are deleted in the process.

➤ Press and hold down the **BND/TS** (15) for longer than two seconds.

The storing procedure begins. The display shows "FM TSTORE" or "AM TSTORE". After the process has completed, the radio will play the station that is stored in memory location 1 of the FMT or AM memory bank.

Listening to stored stations

- Select the memory bank or waveband.
- Press the station button **1 - 5** (12) of the desired station.

Scanning receivable stations (SCAN)

You can use the scan function to play all the receivable stations briefly. You can set the scanning time from 5 to 30 seconds in the menu (in increments of 5 seconds).

Starting SCAN

- Press and hold down the **MENU** button (10) for longer than two seconds.

Scanning begins. "SCAN" appears briefly on the display followed by a flashing display of the current station name or frequency.

Cancelling SCAN and continuing listening to a station

- Press the **MENU** button (10).

Scanning stops and the radio continues playing the station that it tuned into last.

Setting the scanning time

- Press the **MENU** button (10).
- Press the **∨** or **∧** button (6) repeatedly until "SCAN TIME" appears on the display.
- Set the desired scanning time using the **<>** buttons (6).

When you have finished making your changes,

- press the **MENU** button (10) twice.

Note:

The defined scanning time is also applied by the system to scanning carried out in CD and CD changer mode.

CD mode

You can use this device to play standard audio CDs, CD-Rs and CD-RWs with a diameter of 12 or 8 cm.



Caution!

Labelled or shaped CDs can damage the CD drive.

- Do not insert any shape CDs.
 - Do not attach labels to CDs since the label may detach during operation.
-

Note:

Label CDs only by using a marker since it does not contain any caustic materials. Permanent markers can damage CDs.

To ensure proper functioning, use only CDs with the Compact-Disc logo. Copy-protected CDs can cause playback problems. Blaupunkt cannot guarantee the proper functioning of copy-protected CDs!

Besides being able to play audio CDs on this device, you can also play CDs containing MP3/WMA music files. For further information, please read the chapter entitled "MP3/WMA mode".

Switching to CD mode

If there is no CD inserted in the drive,

- ➔ gently insert the CD with its printed side up into the CD tray (4) until you feel some resistance.

The drive draws in the CD automatically.

You must not assist or hinder the drive as it draws in the CD.

The CD starts playing.

The display shows the CD symbol.

Notes:

- The CD symbol indicates that a CD is located in the drive.
A border surrounding the CD symbol indicates that CD is selected as audio source.
- If the vehicle ignition was switched off prior to inserting the CD, you must switch the device on first with the button (2) to start the playback.

If a CD is already inserted in the drive,

- ➔ press the **SRC/⏻** button (14) repeatedly until "CD" appears on the display.

Playback begins from the point at which it was last interrupted.

Selecting tracks

- ➔ Press one of the arrow buttons (6) to select the next or previous track.

If you press the **↵** or **⏪** button (6) once, the player will play the current track again from the beginning.

Fast track selection

To quickly select tracks backwards or forwards,

- press and hold down one of the **↶** **↷** buttons (6) until fast-reverse / fast-forward track selection begins.

Fast searching (audible)

To fast search backwards or forwards,

- press and hold down one of the **<** **>** buttons (6) until fast searching backwards / forwards begins.

Random track play (MIX)

- Press the **5 MIX** button (12).

"MIX CD" appears briefly on the display and the MIX symbol lights up. The next randomly selected track will then be played.

Cancelling MIX

- Press the **5 MIX** button (12) again.

"MIX OFF" appears briefly on the display and the MIX symbol disappears.

Scanning tracks (SCAN)

You can scan (briefly play) all the tracks on the CD.

- Press and hold down the **MENU** button (10) for longer than two seconds.

The next track will then be scanned.

Note:

You can set the scanning time. For further information, please read the section entitled "Setting the scanning time" in the "Radio mode" chapter.

Cancelling SCAN and continuing listening to a track

- To stop scanning, press the **MENU** button (10).

The currently scanned track will then continue to be played normally.

Repeating tracks (REPEAT)

If you want to repeat a track,

- press the **4 RPT** button (12).

"RPT TRCK" appears briefly on the display and the RPT symbol is displayed. The track is repeated continuously until you deactivate RPT.

Cancelling REPEAT

If you want to cancel the repeat function,

- press the **4 RPT** button (10) again.

"RPT OFF" appears briefly on the display and the RPT symbol disappears. Normal playback is then resumed.

Interrupting playback (PAUSE)

- Press the button **3** **⏸** (12).

"PAUSE" appears on the display.

Cancelling pause

- During the pause, press the button **3** **⏸** (12).

Playback is continued.

Configuring the display

You can select from two display types for CD mode:

- Track number and time
- Track number and playing time

To change the display,

- Press and hold down the **DIS** button (9) for longer than 2 seconds.

Displaying CD text

Some CDs include CD text. The CD text might contain the names of the artist, album and tracks.

You can allow the CD text to be displayed as scrolling text every time you switch to another track. The default display will appear again after the whole CD text has been shown once. For further information, please read the section entitled "Configuring the display".

Switching CD text on/off

- Press the **MENU** button (10).
- Press the **↓** or **↑** button (6) repeatedly until "CD TEXT" appears on the display.
- Switch the CD text function on ("TEXT ON") or off ("TEXT OFF") using the **<** or **>** button (6).

When you have finished making your changes,

- press the **MENU** button (10) twice.

Ejecting a CD

- Press the **▲** button (7) next to the CD compartment.

The CD is ejected.

- Remove the CD.

Notes:

- If a CD is ejected, the drive will automatically draw it back in again after approx. 10 seconds.
- You can also eject CDs whilst the device is switched off or whilst another audio source is activated.

MP3/WMA mode

You can also use this car sound system to play CD-Rs and CD-RWs that contain MP3 music files. You can also play WMA files. The operation for playing MP3 and WMA files is identical.

Notes:

- WMA files with Digital Rights Management (DRM) from online music shops cannot be played with this device.
- WMA files can only be played back safely if they were created with Windows Media Player version 8.


Preparing an MP3/WMA CD

The various combinations of CD burners, CD burning software and CD blanks may lead to problems arising with the device's ability to play certain CDs. If problems occur with your own burned CDs, you should try another brand of CD blank or choose another colour of CD blank.

The format of the CD must be ISO 9660 Level 1/Level 2 or Joliet. Other formats cannot be played reliably.

You can create a maximum of 252 directories on a CD. You can use this device to access all of these directories individually.

Regardless of the number of directories on the CD, the device can handle up to 511 MP3 files on a single CD, with a maximum of 255 files in one directory.



(A) Directories

(B) Title · Files

You can name each directory using a PC. The device is capable of displaying the directory name. Name the directories and tracks/files using your CD burner software. The software's instruction manual will provide details on how to do this.

Note:

When naming directories and tracks/files you should avoid using accents and special characters.

If you like your files to be in the correct order, you should use burner software that places files in alphanumerical order. If your software does not provide this feature you also have the option of sorting the files manually. For this purpose, you must enter a number in front of each file name, e.g.

"001", "002", etc. The leading zeros must also be entered.

MP3 tracks can contain additional information such as the artist, album and track names (ID3 tags). This device can display ID3 tags (version 1).

When creating (encoding) MP3 files from audio files, you should use bit rates up to a maximum of 256 Kbit/sec.

This device can only play MP3 files that have the ".MP3" file extension.

Notes:

To ensure uninterrupted playback,

- do not try changing the file extension to ".MP3" of any files other than MP3 files and then attempt to play them! The device will ignore these invalid files during playback.
- Do not use "mixed" CDs containing both non-MP3 data and MP3 tracks (the device only reads MP3 files during MP3 playback).
- Do not use mix-mode CDs containing both CD-audio tracks and MP3 tracks. If you try playing a mix-mode CD, the device will only play the CD-audio tracks.

Switching to MP3 mode

MP3 mode is activated in the same way as normal CD mode. For further information, please read the section entitled "Switching to CD mode" in the "CD mode" chapter.

Configuring the display

The following settings require that an MP3 CD is in the device.

Configuring the default display

You can display various types of information on the current track:

- Track number and playing time "TRCK-TIME"
- Track number and time "TRCK-CLK"
- Directory number and track number "DIR-TRCK"
- Directory number and time "DIR-CLK"
- Directory number and playing time "DIR-TIME"

Note:

After the MP3 scrolling text was scrolled once after a track change, the information is permanently shown on the display.

To switch between the different display options,

- ➡ press and hold down the **DIS** button  for longer than 2 seconds.
- ➡ For an additional selection, press and hold down the **DIS** button  for longer than 2 seconds.

Configuring the MP3 scrolling texts

One of the following scrolling texts is shown once on the display with every track change. Afterwards, the configured standard display is shown.

The available scrolling texts are:

- Directory name ("DIR NAME")
- Name of the track ("SONG NAME")
- Name of the album ("ALBM NAME")
- Name of the artist ("ARTIST")
- File name ("FILE NAME")

Note:

Artist, track and album name are part of the MP3-ID tag of version 1 and can only be displayed if they have been saved with the MP3 files (for further information, please read the instructions that came with your PC's MP3 software or burner software).

To switch between the different display options,

- press the **MENU** button (10).
- Press the **▼** or **▲** button (6) repeatedly until "MP3 DISP" appears on the display.
- Select the desired MP3 scrolling text with the **<** or **>** button (6).

When you have finished making your changes,

- press the **MENU** button (10) twice.

Selecting a directory

To move up or down to another directory,

- press the **▼** or **▲** button (6) once or several times.

Selecting Tracks/Files

to move up or down to another track/file in the current directory,

- press the **<** or **>** button (6) once or several times.

If you press the **<** button (6) once, the current track will be played again from the beginning.

Fast search

To fast search backwards or forwards,

- press and hold down the **<** or **>** button (6) until fast searching backwards / forwards begins.

Random track play (MIX)

To play the tracks in the current directory in random order,

- briefly press the **5 MIX** button (12).

"MIX DIR" appears on the display and the MIX symbol lights up.

To play all the tracks contained on the inserted MP3 CD in random order,

- press and hold down the **5 MIX** button (12) for longer than two seconds.

"MIX CD" appears on the display and the MIX symbol lights up.

Cancelling MIX

To cancel MIX,

- briefly press the **5 MIX** button (12).

"MIX OFF" appears on the display and the MIX symbol disappears.

Scanning tracks (SCAN)

You can scan (briefly play) all the tracks on the CD.

- Press and hold down the **MENU** button (10) for longer than two seconds. The next track will then be scanned.

"TRK SCAN" appears on the display next to the flashing track numbers. The titles of the CD are scanned in ascending order.

Note:

You can set the scanning time. For further information on setting the scanning time, please read the section entitled "Setting the scanning time" in the "Radio mode" chapter.

Cancelling SCAN and continuing listening to a track

➔ Briefly press the **MENU** button (10).

The currently scanned track will then continue to be played normally.

Repeating individual tracks or whole directories (REPEAT)

To play the current track repeatedly,

➔ briefly press the **4 RPT** button (12).

"RPT TRCK" appears briefly on the display and RPT lights up.

To repeat the whole directory,

➔ press and hold down the **4 RPT** button (12) for longer than two seconds.

"RPT DIR" appears briefly on the display.

Cancelling REPEAT

To stop the current track or current directory from being repeated,

➔ briefly press the **4 RPT** button (12).

"RPT OFF" appears briefly on the display and RPT disappears.

Interrupting playback (PAUSE)

➔ Press the button **3 ||▶** (12).

"PAUSE" appears on the display.

Cancelling pause

➔ During the pause, press the button **3 ||▶** (12).

Playback is continued.

CD-changer mode

Note:

Information on handling CDs, inserting CDs and operating the CD changer can be found in the operating instructions supplied with your CD changer.

Switching to CD-changer mode

➔ Press the **SRC/⏻** button (14) repeatedly until "CHANGER" appears on the display.

A border appears around the CD changer symbol.

The device starts playing the first CD that the CD changer detects.

Selecting CDs

To move up or down to another CD,

➔ press the **⏮** or **⏭** button (6) once or several times.

Note:

The device will ignore empty CD slots in the changer and slots containing invalid CDs.

Selecting tracks

To move up or down to another track on the current CD,

➔ press the **<** or **>** button (6) once or several times.

Fast searching (audible)

To fast search backwards or forwards,

- press and hold down one of the <> buttons (6) until fast searching backwards / forwards begins.

Configuring the display

Five options are available for the display in CD changer mode:

- Track number and playing time ("TRCK-TIME")
 - Track number and time ("TRCK-CLK")
 - CD number and track number ("CD-TRCK")
 - CD number and time ("CD-CLK")
 - CD number and playing time ("CD-TIME")
- Press and hold down the **DIS** button (9) for longer than 2 seconds.
- For an additional selection, press and hold down the **DIS** button (9) for longer than 2 seconds.

Repeating individual tracks or whole CDs (REPEAT)

To repeat the current track,

- briefly press the **4 RPT** button (12).

"RPT TRCK" appears briefly and RPT lights up on the display.

To repeat the current CD,

- press and hold down the **4 RPT** button (12) for longer than two seconds.

"RPT DISC" appears briefly and RPT lights up on the display.

Cancelling REPEAT

To stop the current track or current CD from being repeated,

- briefly press the **4 RPT** button (12).

"RPT OFF" appears and RPT disappears on the display.

Random track play (MIX)

To play the tracks on the current CD in random order,

- briefly press the **5 MIX** button (12).

"MIX CD" appears briefly and MIX lights up on the display.

To play the tracks on all inserted CDs in random order,

- press and hold down the **5 MIX** button (12) for longer than two seconds.

"MIX ALL" appears briefly and MIX lights up on the display.

Cancelling MIX

- Briefly press the **5 MIX** button (12).

"MIX OFF" appears and MIX on the display disappears.

Scanning all tracks on all CDs (SCAN)

To scan (briefly play) all the tracks on all the inserted CDs in ascending order,

- press and hold down the **MENU** button (10) for longer than two seconds.

"TRK SCAN" appears on the display and the number of the current track flashes.

Stopping SCAN

To stop scanning,

- briefly press the **MENU** button (10).

The currently scanned track will then continue to be played normally.

Note:

You can set the scanning time. For further information, please read the section entitled "Setting the scanning time" in the "Radio mode" chapter.

Interrupting playback (PAUSE)

- Press the button **3**  (12).

"PAUSE" appears on the display.

Cancelling pause

- During the pause, press the button **3**  (12).

Playback is continued.

CLOCK time

Displaying the time

To briefly display the time,

- press and hold the **SRC/⏻** button (14) until the time appears on the display.

Setting the time

To set the time,

- press the **MENU** button (10).
- Press the **∨** or **∧** button (6) repeatedly until "CLOCK SET" appears on the display.

- Press the **<** button (6).

The time appears on the display. The hours flash and can be adjusted.

- Adjust the hours with the **∨∧** buttons (6).

Once the hours are set,

- press the **>** button (6).

The minutes flash.

- Adjusts the minutes with the **∨∧** buttons (6).

- Press the **MENU** button (10) twice.

Selecting 12/24-hour clock mode

- Press the **MENU** button (10).

The display shows "MENU".

- Press the **∨** or **∧** button (6) repeatedly until "24 H MODE" or "12 H MODE" appears on the display.

- Press the **<** or **>** button (6) to switch between the modes.

When you have finished making your changes,

- ➔ press the **MENU** button (10).

Displaying the time continuously when the device is off and the ignition is on

To display the time when the device is off and the vehicle ignition is on,

- ➔ press the **MENU** button (10).

The display shows "MENU".

- ➔ Press the **∨** or **∧** button (6) repeatedly until "CLOCK OFF" or "CLOCK ON" appears on the display.

- ➔ Press the **<** or **>** button (6) to switch the display between ON and OFF.

When you have finished making your changes,

- ➔ press the **MENU** button (10).

Sound

You can adjust the sound settings (bass and treble) separately for each source (radio, CD, CD changer or AUX).

The volume distribution settings (balance and fader) apply to all the audio sources.

Note:

If bass and treble allow only a limited adjustment, set the equaliser presetting to EQ OFF.

For further details, please read the section "Equaliser presets".

Adjusting the bass

- ➔ Press the **AUDIO** button (11).

"BASS" appears on the display.

- ➔ Press the **∨** or **∧** button (6) to adjust the bass.

When you have finished making your changes,

- ➔ press the **AUDIO** button (11).

Adjusting the treble

- ➔ Press the **AUDIO** button (11).

"BASS" appears on the display.

- ➔ Press the **>** button (6) repeatedly until "TREBLE" appears on the display.

- ➔ Press the **∨** or **∧** button (6) to adjust the treble.

When you have finished making your changes,

- ➔ press the **AUDIO** button (11).

Setting the left/right volume distribution (balance)

To adjust the left/right volume distribution (balance),

- press the **AUDIO** button (11).
"BASS" appears on the display.
- Press the > button (6) repeatedly until "BAL" appears on the display.
- Press the **∨** or **∧** button (6) to adjust the left/right volume distribution.

When you have finished making your changes,

- press the **AUDIO** button (11).

Adjusting the front/rear volume distribution (fader)

To adjust the front/rear volume distribution (fader),

- press the **AUDIO** button (11).
"BASS" appears on the display.
- Press the > button (6) repeatedly until "FADER" appears on the display.
- Press the **∨** or **∧** button (6) to adjust the front/rear volume distribution.

When you have finished making your changes,

- press the **AUDIO** button (11).

Equalizer presets (Presets)

This device features an equalizer in which the settings for the music genres "ROCK", "POP" and "CLASSIC" are already programmed.

To select an equalizer preset,

- Press the **AUDIO** button (11).
"BASS" appears on the display.
- Press the > button (6) repeatedly until "POP", "ROCK", "CLASSIC" or "EQ OFF" appears on the display.
- Press the **∨** or **∧** button (6) to select one of the presets or select "EQ OFF" to switch off the equalizer.

When you have finished making your changes,

- press the **AUDIO** button (11).

Note:

By selecting an equaliser preset (POP, ROCK, CLASSIC), the adjustment range of the sound setting for bass and treble is restricted.

X-BASS

X-Bass allows you to increase the bass at low volume.

The selected X-Bass setting is effective for all audio sources (radio, CD, CD changer or AUX).

The X-BASS increase can be set in increments of 1 to 3.

"XBASS OFF" means that the X-BASS function is switched off.

Adjusting the X-BASS boost

➔ Press the **X-BASS** button (13).

"X-BASS" appears on the display.

➔ Press the **∇** or **∧** button (6) repeatedly until the desired setting appears on the display.

When you have finished making your changes,

➔ press the **X-BASS** button (13).

External audio sources

Instead of the CD changer, you can also connect another external audio source equipped with a line output. Audio sources can, for example, be portable CD players, MiniDisc players or MP3 players.

If you want to connect an external audio source, you will need an adapter cable. You can obtain this cable (Blaupunkt no.: 7 607 897 093) from your authorised Blaupunkt dealer.

Note:

If no CD changer is connected, the AUX input must be switched on in the menu.

Switching the AUX input on/off

➔ Press the **MENU** button (10).

The display shows "MENU".

➔ Press the **∇** or **∧** button (6) repeatedly until "AUX OFF" or "AUX ON" appears on the display.

➔ Press the **<** or **>** button (6) to switch AUX on or off.

When you have finished making your changes,

➔ press the **MENU** button (10).

Note:

If the AUX input is switched on, you can select it by pressing the **SRC/Ⓞ** button (14). The display shows "AUX INPUT" and a border appears around the AUX symbol.

Specifications

Amplifier

Output power: 18W RMS x 4ch @ 14.4V
@ 4ohm @ 1% THD

Tuner

Frequency ranges USA:

FM: 87.5 - 107.9 MHz
(200 kHz step)

AM: 530 - 1710 kHz
(10 kHz step)

Frequency ranges Europe:

FM: 87.5 - 108 MHz
(100 kHz step auto/
50 kHz manual)

AM: 531 - 1602 kHz
(9 kHz step)

Frequency ranges Thailand:

FM: 87.5 - 108 MHz
(50 kHz step auto/
25 kHz step manual)

AM: 531 - 1602 kHz
(9 kHz step)

Frequency ranges South America:

FM: 87.5 - 107.9 MHz
(100 kHz step auto/
50 kHz step manual)

AM: 530 - 1710 kHz
(10 kHz step)

FM mono sensitivity:

17 dbf

FM frequency response:

35 - 16,000 Hz

CD

Frequency response:

20 - 20,000 Hz

Pre-amp out

4 channels: 2 V

Input sensitivity

AUX input: 2 V / 6 kΩ

Weight

approx. 1.3 kg

Subject to changes!

Installation instructions



Safety instructions

When carrying out installation work and making connections please observe the following safety instructions:

- Disconnect the negative terminal of the battery! When doing so, please observe the vehicle manufacturer's safety instructions.
- Make sure you do not damage vehicle components when drilling any holes.
- The cross sections of the positive and negative cables must not be less than 1.5 mm².
- **Do not connect the vehicle's plug connectors to the radio!**
You can obtain the adapter cable required for your vehicle type from any BLAUPUNKT dealer.
- Depending on the model, your vehicle may differ from the description provided here. We accept no responsibility for any damages due to incorrect installation or connection or for any consequential damages.

If the information provided here is not suitable for your specific installation requirements, please contact your Blaupunkt dealer, your vehicle manufacturer or our telephone hotline.

When installing an amplifier or changer, you must first connect the device earth connections before connecting the plugs for the line-in or line-out jacks.

Earth connection of external devices may not be connected to earth of car sound system (housing).

Notice de montage









Consignes de sécurité


Respecter les consignes de sécurité suivantes pendant la durée du montage et du branchement.

- Débrancher le pôle (-) de la batterie !
Respecter les consignes de sécurité du constructeur automobile !
- Veiller à n'endommager aucune pièce du véhicule en perçant des trous.
- La section du câble (+) et (-) ne doit pas dépasser 1,5 mm².
- **Ne pas brancher les connecteurs du véhicule sur la radio !**
Les câbles d'adaptation nécessaires pour le type de véhicule sont disponibles auprès des revendeurs BLAUPUNKT.
- En fonction du modèle, votre véhicule peut différer de cette description. Nous déclinons toute responsabilité en cas de dommages causés par des erreurs de montage ou de connexion et en cas de dommages consécutifs.

Supplied Mounting Hardware
Materiel de montage fourni
Ferretería de montaje suministrada
Elementos de fixação fornecidos
 已提供的硬体装备
 공급된 장착용 하드웨어




Available as an optional accessory
Disponible en option
De venta como accesorios especiales
Disponíveis como acessórios opcionais
 可作为选择性附件
 선택 액세서리로 별도 구입이 가능합니다




7 607 621 ...

Installation kits
Kits de montage
Juegos de montaje
Kits de montagem
 安装工具
 설치 도구 세트




7 608


1.




2.




3.



4.



5. Removal / Démontage / Desmontaje / Desmontagem / 拆除 / 제거하기



ENGLISH


FRANÇAIS

ESPAÑOL


PORTUGUÊS

中文


한국어



6.



7.






Aut. antenna
 FB +12V / RC +12V
 +12V Amplifier

*
 Sum
 Somme
 Suma
 Soma
 总和
 합계

300 mA

| A | | B | |
|---|-----------------|---|-----------------|
| 1 | No connection | 1 | Speaker out RR+ |
| 2 | Radio Mute | 2 | Speaker out RR- |
| 3 | No connection | 3 | Speaker out RF+ |
| 4 | Permanent +12V | 4 | Speaker out RF- |
| 5 | Aut. antenna | 5 | Speaker out LF+ |
| 6 | No connection | 6 | Speaker out LF- |
| 7 | Kl.15/Ignition* | 7 | Speaker out LR+ |
| 8 | Masse/GND | 8 | Speaker out LR- |


| C | | | | | |
|----|--|----|------------------------------------|----|---------------------------------|
| C1 | | C2 | | C3 | |
| 1 | Line Out LR | 7 | No connection | 13 | CDC-Data - In |
| 2 | Line Out RR | 8 | No connection | 14 | CDC-Data - Out |
| 3 | Line Out / Ground | 9 | Radio Mute | 15 | Permanent +12V |
| 4 | Line Out LF | 10 | <input type="checkbox"/> RC +12V * | 16 | <input type="checkbox"/> +12V * |
| 5 | Line Out RF | 11 | Remote Control | 17 | Bus / GND |
| 6 | <input type="checkbox"/> +12V Amplifier* | 12 | RC - GND | 18 | AF / GND |
| | | | | 19 | CDC Line In - L |
| | | | | 20 | CDC Line In - R |



ENGLISH
FRANÇAIS
ESPAÑOL
PORTUGUÊS
中文
한국어

8.

Preamp./Sub./Center - out cable



Subject to changes!
 Sous réserve de modifications!
 Modificaciones reservadas!
 Sob reserva de alterações!
 将随时更改!
 이 정보는 변경될 수 있습니다!