

User guide

Parrot MINIKIT Slim / Chic

English



Index

Index	2
Introduction	3
Using the PARROT MINIKIT Slim/Chic for the 1st time	4
Charging the Parrot MINIKIT Slim / Chic	4
Installing the Parrot MINIKIT Slim / Chic.....	4
Accessing the Parrot MINIKIT Slim / Chic menu.....	5
Pairing and connecting a phone / PDA by Bluetooth.....	5
Using the telephony function	6
Synchronising the phonebook	6
Receiving a call.....	6
Making a call.....	6
Using the redial function	7
Using the discreet mode.....	7
Answering a second call	7
Sending DTMFs	8
Adjusting the volume	8
Using the Voice Recognition function	9
Making a call via voice recognition	9
Updating the Parrot MINIKIT Slim / Chic	10
Hotline	11

Introduction

The *Bluetooth*® technology enables voice and data to be sent via a short-distance radio link. It allows several electronic devices to communicate with each other, particularly phones and hands-free kits.


Parrot is drawing on its long years of experience in signal processing and voice recognition technology to offer a hands-free kit with superior audio quality during calls: the Parrot MINIKIT Slim / Chic.

The Parrot MINIKIT SLIM is a portable *Bluetooth* hands-free kit sporting a profiled, sleek design. Thanks to its space-saving design, it offers countless uses: in the car, in the office and at home. Its highly intuitive interface will automatically connect to your *Bluetooth* phone when nearby. Fixed to the sun visor or laid on a table, it adapts to every environment and can easily be carried around in your pocket.

Using the PARROT MINIKIT Slim/Chic for the 1st time

Charging the Parrot MINIKIT Slim / Chic

- The Parrot MINIKIT Slim / Chic must be charged before being used for the first time. To do so, plug the charger into your vehicle's cigar lighter or connect the Parrot MINIKIT Slim / Chic to your computer using the USB/mini USB cable (provided).



- > The LED located next to the mini-USB port turns red to indicate that the battery is being charged.
 - > The LED turns off once the battery is fully charged.
- When the battery level is low, the Parrot MINIKIT Slim / Chic emits a series of beeps.



The cigar lighter charger of the Parrot MINIKIT Slim / Chic can only be used in cars.

Installing the Parrot MINIKIT Slim / Chic

- Use the clip located on the back of the Parrot MINIKIT Slim / Chic to fix it to the sun visor of your vehicle.



- You can also use your Parrot MINIKIT Slim / Chic at home by simply placing it on a stable surface.

Accessing the Parrot MINIKIT Slim / Chic menu

Press the red button for 2 seconds to turn on the Parrot MINIKIT Slim / Chic.

- Press the jog wheel to access the main menu.
> The Parrot MINIKIT Slim / Chic says the name of the current menu.
- Browse through the menus by turning the jog wheel and confirm with the green button or by pressing the jog wheel.
- To exit the menu, press the red button or wait for a few seconds.

Pairing and connecting a phone / PDA by Bluetooth

Before using the Parrot MINIKIT Slim / Chic with your phone, you first have to pair both devices. The pairing process is only required once. Depending on the model of your phone, the connection will then be automatic as soon as you enter your vehicle.

1. From your *Bluetooth* phone, search for *Bluetooth* peripherals (refer to your phone user guide for more information).
> The list of the available *Bluetooth* peripherals is displayed.
2. Select «**Parrot MINIKIT Slim / Chic**».
3. Enter the «**1234**» PIN code and validate.
> The Parrot MINIKIT Slim / Chic says «Pairing successful» when both devices are paired.



You can pair up to five devices. If you attempt to pair a sixth phone, the kit says «memory full». You must clear the memory by holding down both the red and green buttons for three seconds. Doing so also clears all the contacts and the associated voice tags.

Using the telephony function

Before using your Parrot MINIKIT Slim / Chic telephony function, you first have to pair and connect both devices.

► Refer to the **Pairing and connecting a phone via Bluetooth** section for more information.

Synchronising the phonebook

With some *Bluetooth* phones, the phonebook is automatically synchronized in the kit's memory. If your phone doesn't support automatic synchronization, you can also use the Object Push function of your phone to send contacts from your mobile to the car kit via *Bluetooth*. To do so:

1. From the main menu, select **Phone > Receive contacts**.
> The kit says «Waiting for contact».
2. Refer to your phones' user guide for more information about sending contacts via Object Push.

Receiving a call

An incoming call is indicated by a ringtone.



The name of the caller is announced if his number is recorded in the phonebook of the phone connected to the Parrot MINIKIT Slim / Chic.

- If you want to answer the call, press the green button. Then press the red button to end the call.
- If you want to refuse this call, press the red button.

Making a call

- If the contact you want to call is in the phonebook of the phone connected to the Parrot MINIKIT Slim / Chic:
 1. Press the jog wheel to enter the main menu and select **Phonebook**.
> You access the phonebook of the connected phone.
 2. Select a letter and press the jog wheel.
> Once the contact chosen:
 - Press the green key to call this contact;
 - Use the jog wheel to choose between different numbers of the same contact.
- If the contact you want to call is not in the phonebook of the

phone connected to the Parrot MINIKIT Slim / Chic, stop your vehicle in a safe location and use your phone to make the call.

Using the redial function

Hold down the green key of the Parrot MINIKIT Slim / Chic to call the last number dialed.

Using the discreet mode

- If you want to transfer an ongoing call on your mobile phone, press the green key of the Parrot MINIKIT Slim / Chic.
 - > The call is automatically transferred to your phone.
 - If you want to switch back to the kit, press the green key again.
-

Answering a second call

The Parrot MINIKIT Slim / Chic allows you to manage two calls simultaneously if your phone supports this functionality. For further information, refer to the user guide of your phone.

- To accept the second call
 1. Press the green key of the Parrot MINIKIT Slim / Chic.
 - > The first call is automatically put on hold.
 2. Press the key of the kit or of your phone to switch from a call to another.
 3. Press the red key of the Parrot MINIKIT Slim / Chic to end a call. You can also hang-up directly from your phone.
 - > You are automatically in communication with the call on hold.
- To reject the second call

Press the red key of the Parrot MINIKIT Slim / Chic. You can also reject it directly from your phone.

Sending DTMFs

During a call, the Parrot MINIKIT Slim / Chic allows you to send DTMFs to manage your voice mail for example. To do so :

1. Appuyez sur la molette pour accéder au menu des DTMF.
> « 0 » est énoncé par le kit mains libres.
2. Use the jog wheel to select your DTMF between the following possibilities : 0,1,2,3,4,5,6,7,8,9,# or *.
3. Press the jog wheel to send this DTMF to your phone.

Adjusting the volume

During a call, use the jog wheel on the Parrot MINIKIT Slim / Chic or adjust the volume directly on your phone.
> The volume setting is saved for subsequent calls.



The volume adjusted on the Parrot MINIKIT Slim / Chic is not saved for the calls on your phone.

Using the Voice Recognition function

Before using your Parrot MINIKIT Slim / Chic voice recognition function, you first have to pair and connect both devices.

► Refer to the **Pairing and connecting a phone via Bluetooth** section for more information.

Making a call via voice recognition



This functionality is only available if your contacts have already been transferred into the phonebook of the Parrot MINIKIT Slim / Chic.

1. Press the green key to launch the voice recognition feature.
> A beep is emitted.
2. Say the « **Call** » keyword and the name of the contact you want to call.
> The call is automatically launched if the voice tag is correctly understood. If it is not the case, a confirmation message is asked by the kit.



You can make a call via voice recognition using several combinations of keywords. For example, « call 'Paul' » or simply « 'Paul' ». You can also associate the type of number you want to call: « call 'Paul' at home », « 'Paul' home », etc.



3. Confirm by saying « **yes** » or « **call** ».
> The call is initiated.

Updating the Parrot MINIKIT Slim / Chic

In order to improve the compatibility of your Parrot MINIKIT Slim / Chic with a larger number of phones, you can update the software of your device via USB. Before sending the update files via USB:

1. Press simultaneously the jog wheel and the Reset button located at the back of the Parrot MINIKIT Slim / Chic.
2. Release the jog wheel.
> You can now release the Reset button.



In case of malfunction, you can reboot the Parrot MINIKIT Slim / Chic. To do so:

- 1. Press simultaneously the jog wheel and the Reset button located at the back of the Parrot MINIKIT Slim / Chic.*
- 2. Release the Reset button.*
> *You can now release the jog wheel.*

Hotline

Our hotline is at your disposal from Monday to Friday between 9am and 6 pm (GMT+1) by mail hot-line@parrot.com or by phone:

Europe: [+33] (0) 1 48 03 60 69 (Spoken languages: English, French, Spanish and German)

Italy: [+39] 02 59 90 15 97

Spain: [+34] 902 404 202

UK: [+44] (0)870 112 5872

Germany: 0900 172 77 68

USA: [+1] (877) 9 PARROT (toll free)

China: [+ 86] (0)2164 601 944