

User Guide

Parrot MKi9200

English



Content

Content	2
Introduction	4
Installing the Parrot MKi9200	5
Car stereo with ISO connectors	5
Car stereo with line-in.....	6
Car stereo without ISO connectors	6
Installing the electronic box	6
Installing the kit's power cable.....	7
Checking the wiring	7
Installing the audio connectors	7
Installing the remote control.....	7
Installing the double microphone.....	8
Installing the screen.....	9
Using the Parrot MKi9200 for the 1st time	10
Associating the control unit with the remote control	10
Navigating through the menus	10
Adjusting the menu volume	10
Pairing and connecting a phone / PDA via Bluetooth	10
Synchronizing the phonebook	11
Clearing the memory	11
Using the Voice Recognition function	12
Making a call via voice recognition	12
Receiving a call via voice recognition.....	13
Using the telephony function.....	14
Receiving a call	14
Making a call	14
Using the redial function.....	14
Using the discreet mode	15
Using the secret mode	15

Answering a second call	15
Sending DTMFs	16
Adjusting the	16
volume	16
Using the Music function	17
Selecting a music source	17
Using the remote control during music files playback	18
• Pausing during playback	18
• Fast rewinding / fast forwarding the current track	18
• Selecting music files	18
• Adjusting the volume	18
• Accessing to the audio effects menu	18
Modifying the display settings	19
Adjusting the brightness	19
Changing the wallpaper	19
• Selecting a wallpaper proposed by default	19
• Customizing the wallpaper	19
Modifying the audio settings	21
Activating the vocal menus	21
Adjusting the ringtone volume	21
Activating the lateral noise detection	21
Deactivating the Mute on Streaming	21
Activating the spatialization	21
Activating the equalizer	22
Activating the Virtual Super Bass effect	22
Activating the Repetition / Random options	22
Updating your Parrot MKi9200	23
Hotline	23

Introduction

The *Bluetooth*® technology enables voice and data to be sent via a short-distance radio link. It allows several electronic devices to communicate with each other, particularly phones and hands-free kits.

Parrot is drawing on its long years of experience in signal processing and voice recognition technology to offer a hands-free car with superior audio quality during calls: The Parrot MKi9200.

Once paired with your Bluetooth mobile phone, the Parrot MKi9200 enables you to establish in a few seconds any phone conversations in your vehicle without needing to handle the telephone, even leaving it in your pocket. Connection with your mobile is made in a completely transparent way.

The user-independent voice recognition and voice synthesis are integrated in your Parrot MKi9200, which dramatically ease the way of using them in every situation. And all the connectors for any type of music are provided: iPod, iPhone, iTouch, USB keys, USB MP3 players, Bluetooth Stereo devices, CD players, MiniDisc...



A steering wheel control interface can be used to connect your vehicle's steering wheel controls to your Parrot hands-free kit. With this interface, you will be able to make phone calls via the steering wheel controls while keeping your hands on the wheel. Refer to our website www.parrot.com for more information.

Installing the Parrot MKi9200




We advise our customers to have the Parrot MKi9200 fitted by a professional.

- Remove the audio system from your vehicles dashboard to access the wiring harness.
- The cables supplied with the kit feature ISO connectors and two pairs of line-out jacks. The line-out jacks can be used if your audio system features this option (use of an amplifier). Several set-ups are therefore possible depending on the type of car stereo and your vehicle.
- The mute function is used to cut the sound of your car stereo to enable a phone call. The choice of the mute-in jack depends on your car stereo's configuration.
- Make sure the cables are not pinched at the end of the installation process.


Car stereo with ISO connectors

1. Connect the male connectors of the hands-free kit to the car stereo.
2. Join the vehicle's audio and power supply cables to the female connectors of the Parrot MKi9200.
3. On the installation cable, connect the free yellow wire to one of the audio system's corresponding mute-in jacks if available (mute in 1, mute in 2 or mute in 3).



Car stereo with line-in

- Use this type of connection by wiring the line-out (brown & white wire or red & black wire) to your car stereo's line-in.
- Using the two pairs of line-out will enable you to take advantage of the streaming audio function in stereo over your vehicle's speakers.
- On the installation cable, connect the free yellow wire to the corresponding audio system's mute-input if available (mute in 1, mute in 2 or mute in 3).



Car stereo without ISO connectors

To simplify the wiring procedure, you will need to purchase an ISO adapter cable. Refer to the range of ISO adapters on our website: www.parrot.com.

Installing the electronic box

- Avoid installing the electronic box:
- near heating or air-conditioning system;
 - on a spot directly exposed to sunlight;
 - behind metal walls.

Installing the kit's power cable



In order to check the wiring, connect the screen before placing it on the dashboard.

▶ Refer to the **Checking the wiring** section for more information.

- Refer to your car stereo's wiring diagram.
- The red wire of the kit's cable must correspond to the constant +12V supply, the orange wire to the ignition +12V and the black wire to ground. Check that the orange wire is not connected to the constant +12V supply, as you could run down the vehicle's battery.



On some vehicles, there is no ignition +12V on the vehicle's connectors. You must therefore connect the orange power supply wire to the fuse box or another ignition power source.

Checking the wiring


- To perform the installation check, turn the ignition on then off once the Parrot MKi9200 is installed: the message "Goodbye!" must be displayed.
- If it is not the case, it is necessary to inverse the positions of the red and orange wires. Indeed, the red wire of the power cable must be connected to the permanent 12V, the orange wire to the 12V ignition and the black wire to the ground. This can be done simply by reversing both fuse holders located on the Parrot wiring.

Installing the audio connectors


- Connect the music cable to the electronic box and place the USB / iPod / Jack connectors into the glove box, the central console or the parcel tray depending on the configuration of your dashboard. Make sure that the cable is not pinched.
- Use the provided protection cap to protect the connectors.

Installing the remote control

- Choose the place for the remote control inside your vehicle. We would advise you to fit it in the center of the dashboard or close to the steering wheel.
- If you want to place the remote control on the steering wheel, make sure it is securely attached, so that it does not move when you are driving. Do not install the remote control on the outside of the steering wheel, so that it does not get in the way when driving.



- If you want to place the remote control on the dashboard, stick the double-sided tape located on the flat side of the bracket to fix it against the dashboard. You can then insert the remote onto the bracket.




Once you have stuck the support on the dashboard, wait for approximately 2 hours to make sure the adhesive tape adheres well.

Installing the double microphone

Parrots microphones are directional and need to be pointed towards the user to pick up clear speech. The microphone should be installed near the front roof light cluster, in the centre of the vehicle with a clear path to the user.




Installing the screen

- Once you have stuck the support on the dashboard, wait for approximately 2 hours to make sure the adhesive tape adheres well.
- Remember to remove your screen when leaving the vehicle to avoid tempting any would-be thieves and to prevent prolonged exposure to sunlight.





Using the Parrot MKi9200 for the 1st time

Associating the control unit with the remote control

If the remote control doesn't seem to be associated to the electronic box while using the Parrot MKi9200 for the first time, press several times the  button while holding down the  and  buttons until the «Pairing remote control» message is said. This has to be done during a 30 seconds period once the ignition is turned on.

Navigating through the menus

- Press the central jog wheel to access the menus.
> The kit says the name of the current menu.
- Browse through the menus by turning the wheel and confirm with the  button or by pressing the scroll wheel.
- To exit the menu, press the  button or wait a few seconds.

Adjusting the menu volume

To adjust the volume of the Parrot MKi9200, press the jog wheel and select **Settings > Audio > Menu Volume**. Use the jog wheel to adjust the desired volume then validate.



*The Audio menu also allows you to deactivate the vocal menus. For further information, refer to the **Modifying the audio settings** section.*

Pairing and connecting a phone / PDA via Bluetooth

Prior to using your Parrot MKi9200 with your phone for the very first time, you must initially pair both devices. The pairing process is only required once.


1. Make sure the Parrot MKi9200 is set so that it is visible by all *Bluetooth*® devices. To do so, press the jog wheel and select **Settings > Bluetooth > Visibility**. Then, make sure this option is selected. If it is not the case, select it by pressing the jog wheel.



The Parrot MKi9200 is visible by default.

2. Press the jog wheel and select **Settings > Bluetooth > Pair with....**

- > If your mobile phone's model appears in the list, select it and confirm by pressing the jog wheel.
 - > If your mobile phone model doesn't appear in the list, select the **Other phones** option.
3. From your phone, search for *Bluetooth* peripherals. Refer to your phone user guide for more information.
 - > The list of the available *Bluetooth* peripherals is displayed.
 4. Select « **Parrot MKi9200** » in the list.
 5. Enter « **0000** » on your phone when you are prompted to enter a PIN code.
 - > «Pairing successful» is displayed on the screen of the Parrot MKi9200.

 *Once your phone is paired to the Parrot MKi9200, the connection between both devices will be automatically established each time you enter your vehicle if your screen is plugged in.*

Synchronizing the phonebook

With some *Bluetooth* phones, the Parrot MKi9200 automatically synchronizes the names and phone numbers in your mobile with its phonebook. If your phone doesn't support automatic synchronization, you can also send contacts from your mobile to the car kit via Object Push. To do so:

1. Press the jog wheel and select **Phone > Receive contacts**.
2. Refer to your phones 'user guide for more information about sending contacts via Object Push.

Clearing the memory

You can pair up to 10 devices with the Parrot MKi9200.

If you attempt to pair an 11th phone, the « Memory full » message is displayed on the screen of the Parrot MKi9200. You must then delete a phone from the paired devices list. To do so, press the rotator and select **Settings > Bluetooth > Paired devices**.

Using the Voice Recognition function


Before using your Parrot MKi9200 voice recognition function, you first have to connect it with your phone / PDA.

► Refer to the **Pairing and Connecting a phone via Bluetooth** section for more information.

Making a call via voice recognition



This function is available if you have previously synchronized your contacts in the kit.

1. Press the  button to launch the voice recognition feature.
 - > A beep is emitted.
2. Say the « **Call** » keyword and the name of the contact you want to call.
 - > The call is automatically launched if the voice tag is correctly understood.
 - > If it is not the case, a confirmation message is asked by the kit.



You can make a call via voice recognition using several combinations of keywords. For example, « call 'Bob' » or simply « 'Bob' ». You can also associate the type of number you want to call: «call 'Bob' at home», «'Bob' home », etc.



3. Confirm by saying « **Yes** » or « **Call** ».
 - > The call is initiated.

Receiving a call via voice recognition

- The magic word «**Accept**» allows you to accept an incoming call.
- The magic word «**Refuse**» allows you to reject an incoming call.

To use the magic words, you must activate them. To do so :

1. Press the jog wheel and select **Phone > Voice Commands > Magic words**.
2. Press the jog wheel to activate/deactivate the magic words.



Using the telephony function

Before using your Parrot MKi9200 telephony function, you first have to connect it with your phone / PDA.




► Refer to the **Pairing and Connecting a phone via Bluetooth** section for more information.

Receiving a call


An incoming call is indicated by a ringtone.





The name of the caller is announced and displayed if his details are stored in the phonebook of the phone connected to the Parrot MKi9200.

- If you want to answer the call, press the  button. Then, press the  button to end the call.
- If you want to refuse this call, press the  button.



Making a call

- If the contact you want to call is in the phonebook of the phone connected to the Parrot MKi9200:
 1. Press the jog wheel to enter the main menu and select **Phonebook**.
 2. Select a letter and press the jog wheel.
 - > Once the contact chosen:
 - Press the  button to call this contact.
 - Or use the jog wheel to choose between different numbers of the same contact.
- If the contact you want to call is not in the phonebook of the phone connected to the Parrot MKi9200, stop your vehicle in a safe location, press the jog wheel and select **Phonebook > Dial a number**. You can also make the call directly from your phone.


Using the redial function

Hold down the  key of the Parrot MKi900 for  two seconds to redial the last number dialled.

Using the discreet mode




- During a call, if you want to continue the conversation on your phone (private conversation), press the  button of the Parrot MKi9200.
 - > The call is automatically transferred to the phone.
 - If you want to switch back to the kit, press the  button again.
-


Using the secret mode

- During a call, if you want to deactivate the microphone, hold down the  button for two seconds.
 - Press the same button to activate it again.
-

Answering a second call

The Parrot MKi9200 allows you to manage two calls simultaneously if your phone supports this functionality. For further information, refer to the user guide of your phone.

- To accept the second call
 1. Press the  button of the Parrot MKi9200.
 - > The first call is automatically put on hold.
 2. Press the  button of the Parrot MKi9200 or the green button of your phone to switch from a call to another.
 3. Press the  button of the Parrot MKi9200 to end the current call. You can also hang up directly from your phone.
 - > You are automatically in communication with the call on hold.
- To reject the second call

Press the  button of the Parrot MKi9200. You can also reject it directly from your phone.

Sending DTMFs

During a call, the Parrot MKi9200 allows you to send DTMFs to manage your voice mail for example. To do so :

1. Press the jog wheel to access the DTMF menu.
> « 0 » is displayed by the kit.
 2. Use the jog wheel to select your DTMF between the following possibilities : 0,1,2,3,4,5,6,7,8,9,# or *.
 3. Press the jog wheel to send this DTMF to your phone.
-

Adjusting the volume

During a call, use the jog wheel on the Parrot MKi9200 or adjust the volume directly on your phone.

> The volume setting is saved for subsequent calls.



The volume adjusted on the Parrot MKi9200 is not saved for the calls on your phone.

Using the Music function

Selecting a music source

- Use the USB, Jack or iPod connectors to connect the Parrot MKi9200 to your audio player / iPod / USB stick.




If you are using the Parrot MKi9200 with the iPod Mini, iPod Photo, iPod 3G and iPod Shuffle, then connect your iPod to the Parrot MKi9200 using the Jack cable.

Make sure your iPod is updated before using it with the Parrot MKi9200.

- The Parrot MKi9200 also allows you to play music files stored on an SD card. To transfer music files:
 1. Insert the SD card into the appropriate slot.
 2. Connect the Parrot MKi9200 to your computer using a USB / mini-USB cable.



3. Copy your music files in MP3 or WMA formats as if it was a USB flash drive.
- Press the  button to launch the music function. Press the jog wheel to access the content of the selected source. If the tags of your music files are correctly defined, you can select one of the classification items (artists, genres, albums ...) and press the jog wheel.
 - To change the music source, press the jog wheel and select your audio source in the following order:
 - iPod,
 - USB peripheral,
 - SD card
 - audio player connected via *Bluetooth*,
 - audio player connected via Line-in.



If your Parrot MKi9200 is connected to an iPhone and an USB flash drive, the iPhone has priority: you can only browse through your iPhone content.



While navigating through the menus or when the screensaver is active, press the ▷ button to get back to the music player.

Using the remote control during music files playback

- **Pausing during playback**

When playing music file, press the ▷ button to momentarily stop playback.

Press the ▷ button again to resume playback of the music track.

- **Fast rewinding / fast forwarding the current track**

When playing a music file, hold down the ⏮ and ⏭ buttons to fast rewind or forward the current track.

- **Selecting music files**

When playing a music file, press the ⏮ and ⏭ buttons to change to the previous or next track by pressing the respectively.

During the music files playback, press the 🔍 button to access the content of the selected source. Then, you can navigate and change the music file you're listening to using the jog wheel.



The Next/Previous tracks functions are not available if the Parrot MKi9200 is connected to the audio player via the Jack connector.

- **Adjusting the volume**

When playing a music file, use the jog wheel to adjust the volume.



The volume for calls and the volume for the streaming audio function work separately.

- **Accessing to the audio effects menu**

When playing a music file, hold down the ▷ button for 2 seconds to access to the audio effects menu.



For more information about the audio settings of the Parrot MKi9200, refer to the **Modifying the audio settings** section.

Modifying the display settings

Adjusting the brightness

You can adapt the screen brightness of the Parrot MKi9200. To do so, press the jog wheel and select **Settings > Brightness** then select **Night Mode** or **Day Mode**.



You can also adjust the brightness of the Parrot MKi9200 by holding down the jog wheel.

Changing the wallpaper

You can change the wallpaper of the Parrot MKi9200 by selecting one of the wallpapers proposed by default. You can also customize it by sending a photo directly to the kit.

- **Selecting a wallpaper proposed by default**

1. Press the jog wheel and select **Settings > Display > Wallpaper** then use the jog wheel to choose in the list wallpaper you want to display.
2. Press the jog wheel to validate.

- **Customizing the wallpaper**

1. Make sure the Parrot MKi9200 is set so that it is visible by all *Bluetooth* devices. To do so, press the jog wheel and select **Settings > Bluetooth > Visibility**. Then, make sure this option is selected. If it is not the case, select it by pressing the jog wheel.
2. Press the jog wheel then select **Settings > Display > Wallpaper > Customize > Add**.
> « *Waiting for a picture* » is displayed on the Parrot MKi9200.
3. From your *Bluetooth* peripheral, send via *Bluetooth* the image you want to display on the Parrot MKi9200.
▶ *Refer to your device documentation for more information about sending photos via Bluetooth.*



To delete an image sent as wallpaper on your Parrot MKi9200, press the jog wheel then select **Settings > Display > Wallpaper > Customize > Delete**.

Modifying the audio settings

Activating the vocal menu

You can activate or deactivate the vocal menu of the Parrot MKi9200. To do so, press the jog wheel and select **Settings > Audio > Spoken menu**. Press the jog wheel to activate or deactivate this option.

Adjusting the ringtone volume

To adjust the volume of the ringtone which indicates an incoming call, press the jog wheel and select **Settings > Audio > Ringtone volume** then use the jog wheel to adjust the volume.

Activating the lateral noise detection

- The lateral noise detection of the Parrot MKi9200 allows you to adjust automatically the volume depending on the surrounding noise.
 - To adjust this setting, press the jog wheel and select **Settings > Audio > Lateral noise detection**. Press the jog wheel to activate or deactivate this option.
-

Deactivating the Mute on Streaming

- This option automatically mutes the tuner when a music file is played. This option is activated by default.
 - You can deactivate this option, and so, mute the tuner manually via the Mute cable. To do so, press the jog wheel then select **Settings > Audio > Mute on Streaming**. Press the jog wheel to deactivate this option.
-

Activating the spatialization


The spatialization of the Parrot MKi9200 offers you a three-dimensional sound.

- To adjust this setting, press the jog wheel then select **Audio effects > Spatialization**. Press the jog wheel to activate or deactivate this option.
- After having activated the spatialization, you can modify its characteristics. To do so, select **Audio Effects > Settings > Spatialization settings**.

Activating the equalizer

- The equalizer allows you to adjust the low, medium and high frequencies depending on your preferences. To activate or deactivate it, press the jog wheel and select **Audio effects > Equalizer**. Press the jog wheel to activate or deactivate this option.
- Also, you can choose between 10 default presets to adapt the frequencies to the music style you are listening to. To do so, press the jog wheel then select **Audio > Settings > eq. settings**. Then, use the jog wheel to modify the frequencies.




Hold down the  button for 2 seconds to access the audio effects menu during playback.

Activating the Virtual Super Bass effect

- The Virtual Super Bass effect allows you to amplify the low frequencies. To activate or deactivate it, press the jog wheel and select **Audio effects > Virtual Super Bass**. Press the jog wheel to activate or deactivate this option.
- You can change the settings of the Virtual Super Bass effect by selecting **Audio effects > Settings > Vsb preferences**.



Hold down the  button for 2 seconds to access the audio effects menu during playback.


Activating the Repetition / Random options

- To activate or deactivate the random playback of the music files, press the jog wheel and select **Audio effects > Settings > Random**. Press the jog wheel to activate or deactivate this option.
- To activate or deactivate the repetition of the music files, press the jog wheel and select **Audio effects > Settings > repetition**. Press the jog wheel to activate or deactivate this option.



If you use an iPod with your Parrot MKi9200, select the **Audio effects > Settings > Random (iPod)** and **Audio effects > Settings > Repetition (iPod)** options.



Hold down the  button for 2 seconds to access the audio effects menu during playback.

Updating your Parrot MKi9200

A detailed procedure which explains step by step the update process of your Parrot MKi9200 is available on our website www.parrot.com.

Hotline

Our hotline is at your disposal from Monday to Friday, between 9 am and 6 pm (GMT +1) by mail hot-line@parrot.com or by phone:

Italy: [+39] 02 59 90 15 97

Spain: [+34] 902 404 202

UK: [+44] (0)870 112 5872

Germany: 0900 1727768

USA: [+1] (877) 9 Parrot (toll free)

China: [+86] (0)21 6460 1944

Hong Kong: [+852] 2736 1169

France: 01 48 03 60 69

Europe: [+33] 1 48 03 60 69 (Spoken languages: French, English, Spanish and German)